ESB2x series, E-Stop button acc. to EN ISO 13850 and EN 60947-5-5

Leuze electronic GmbH + Co. KG In der Braike 1, D-73277 Owen - Teck / Germany, Phone: +49 7021 573-0, Fax: +49 7021 573-199, http://www.leuze.com, info@leuze.com

1 Safety and use

This document is to be adhered to for installation, start-up/use and testing of the ESB2x. It must be provided to the affected personnel. As before, all relevant national and international standards and regulations must be observed, including

- Machinery directive 2006/42/EC
- Low voltage directive 2006/95/EC safety regulations
- · Accident-prevention regulations and safety rules
- Ordinance on Industrial Safety and Health and Labor Protection Act
- · Device Safety Act

The manufacturer and operator of the machine are responsible for the proper use, monitoring and testing of the ESB2x E-Stop button as well as compliance with all applicable safety regulations, including:

- EN ISO 13850: 2008
- EN 60947-5-1:2004
- EN 60947-5-5:1997 and Annex 2005

2 Device description and function

Using the 2NC/1NO contact block, the ESB2x E-Stop buttons enable electrical E-Stop command output up to and including safety category 4 and PL e. They are designed acc. to EN ISO 13850:2008 regarding color, shape and symbols. ESB2x are available with rotary or key release. Connection can be done either via cable or M12 plug.


3 Mounting and connection



WARNING

The system is to be brought to a standstill safely and safeguarded against re-starting before mounting and connection.

- Screw the housing base tightly to the force-fit surface.
- ♥ Break the provided cable bushing free.
- Lead through the cable gland with the corresponding sealing class and screw it in firmly.
- ♦ Connection = E-Stop command output to 2 x NC, signaling to NO.



Pin 3	1	~_	2	Pin 4
Pin 5	1		2	Pin 6
Pin 7	3		4	Pin 8

- Blace the upper housing on the lower part and screw it on firmly.
- Put the caps on.
- Observe the technical data.

4 Tests



WARNING

Severe accidents may result if tests are not performed properly.

Make certain that there are no people in the danger zone.

First checks

The ESB2x is force-fit fastened acc. to specifications. Rotation is therefore not possible.

- Switch on the machine.
- Press the button.

♦ Check that the machine has stopped.


Recurring checks

Check that the ESB2x and cable fastenings are free from play and manipulation and that they function properly.

5 EC Declaration of Conformity

You can find the EC Declaration of Conformity with the standards used at http://www.leuze.com.

6 Dimensional drawings



7 Technical data

up to SIL 3	
up to PL e, up to cat. 4	
600,000	
20 years	
-25°C to +80°C	
3	
II	
cULus	
300,000	
20,000,000	
max. 3600 per hour	
2NC/1NO	
Creep contact	
Force-fit	
Silver alloy	
60 mm screen	
25 N	
Structure	
red/yellow-black	
PA/PC	
passageway fastening	
IP67, IP69K	

Article	ESB200-4TR-C	ESB200-4KR-C	ESB200-4TR-M12p	ESB200-4KR-M12p
Screw terminal tightening torque	0.6 - 0.8 Nm	0.6 - 0.8 Nm	N.a.	N.a.
Type of unlocking, turning	button	key	button	key
Cable entries	3 x M20, 2 x M16	3 x M20, 2 x M16	1x	1x
Connection system	Screw terminals	Screw terminals	M12 plug	M12 plug
Permissible wire gauge	0.5 mm ² to 2 x 2.5 mm ²	0.5 mm ² to 2 x 2.5 mm ²	N.a.	N.a.
Conventional thermal current	10 A	10 A	2 A	2 A
Rated insulation voltage Ui	600 V AC/DC	600 V AC/DC	30 V AC, 36 V DC	30 V AC, 36 V DC
Usage category in accordance with EN 60947-5-1, AC15, Ue (V) / Ie (A)	24/6, 48/6, 120/6, 250/6, 400/3	24/6, 48/6, 120/6, 250/6, 400/3	I 24/2	I 24/2
Usage category in accordance with EN 60947-5-1, DC13, Ue (V) / Ie (A)	24/2.5, 48/1.3, 125/0.6, 250/0.3	24/2.5, 48/1.3, 125/0.6, 250/0.3	I 24/2	I 24/2
Short-circuit protection according to IEC 60269-1	500 V, 10 A, type gG	500 V, 10 A, type gG	500 V, 2 A, type gG	500 V, 2 A, type gG
Weight	240 g	240 g	248 g	248 g
Order no.	63000000	63000002	63000004	63000006